

Eyemax CD Copy

Camera Guard Security

(714)964-7697

1. Enter search mode
2. Select day of incident
3. Click Backup (below calendar)
4. Click "Next" to begin backup process
5. Select DFS (default); click "Next"
6. Enter start time & end time (15-20 minutes max)
7. Click "Browse"
8. The "Browse For Folder" window will open
9. Click the + sign for Local Disk (C:)
10. Click the + sign for Documents and Settings
11. Click the + sign for Expedite Video
12. Click the yellow folder for "My Documents"
13. Click button labeled "New Folder" (lower right hand corner of the window)
14. Rename the folder and click on the yellow folder icon to the left of the name once or twice, until the name itself is highlighted
15. Click "Ok"
16. Screen returns to DVR Backup Wizard
17. Click "Next"
18. Put a check mark by each camera listed to include it in the CD Copy
19. Click "Next"
20. Click "Next" again to start backup process
21. When the backup window closes, click on "Control" in the lower right-hand corner
22. Click "Network" in the upper right-hand corner
23. Click on "Start" in the lower left-hand corner of the screen
24. Hover over "Programs", then "Roxio Creator 9.1 XE", then "Data", and click "Creator Classic"
25. Navigate to the "Documents Folder". This can be found by following the steps above (9-12). If you're already in "My Documents", disregard this step.
26. Click on folder created during step 14 to highlight it
27. Click on the "Add" button in the center area of the screen, on the far right-hand side
28. Click on the "Burn" button in the center of the screen
29. In the new window that appears, if it says, "Medium not present - Tray Closed - Unit not ready," then you either have a CD in the drive that is not currently blank or no CD at all. Insert a blank CD now, which should cause the "OK" button to no longer be greyed out.
30. Click "Ok" to start the CD creation process. Once it completes, the CD will automatically eject from the drive
31. Click "No" on the "Save changes to untitled?" window
32. Close all program windows to return to the main video screen